

Installation Instructions for AddressFinder Illuminated Address Sign

Installation Preparation

For maximum efficiency, install your AddressFinder sign in a location that is highly visible from the street. Suggested locations include above the garage door or near the front entrance if the visibility is good.

Tools Required

To install your AddressFinder sign, you will need the items listed:

- Carpenter's (Bullet) Level
- Electric or Cordless Drill
- Tape Measure
- Masking Tape
- Pencil or Marker
- Wire Cutters / Stripper
- Screwdriver
- Hammer
- Step Ladder

Inside the AddressFinder Box

- Engrave Sign (1)
- Carbide Masonry Drill Bit (1)
- Concrete Anchors (2 or 4)
- Mounting Screws (2 or 4)
- Wire Nuts (2)
- Low-voltage Wire
- Plastic Straw (1)
- Instruction Sheet (1)
- Plug-in Adapter (1)

IMPORTANT: Please read through instructions before starting installation.

1. Place your AddressFinder sign against the surface and position correctly where the unit will be mounted.
2. Using a level, ensure the AddressFinder sign is horizontal and level. Mark the 2-mounting holes.
3. Measure a 2-1/4" (6cm) length from the tip of the carbide drill bit provided and mark it with masking tape.
WARNING: When drilling the mounting holes, the depth should not exceed 2-1/4" (6cm)
4. Using the supplied carbide masonry drill bit, drill the 2-holes to a maximum depth of 2-1/4" (6cm) or to where the masking tape starts.
5. Drill one additional hole through the wall for the passage of the low-voltage wiring.
6. Insert the concrete anchors into the outside mounting holes. Tap in with a hammer until flush.
7. Screw in screws provided, to a depth of 1" (2.5cm)
8. Place the AddressFinder sign on top of 1-mounting screw only, letting the unit dangle.
9. Insert the low-voltage wiring from the AddressFinder sign through the straw provided.
10. Insert the straw with the wiring into the hole, leaving 2" (5cm) protruding on the outside of the wall so that there is space to grasp the end of the straw.
11. While holding firmly onto the straw, feed the low-voltage wire through the straw until it protrudes out of the other end on the other side of the wall.
12. Once the wire is fed through the straw, lift the AddressFinder sign and mount it onto all mounting screws.
13. Pull the AddressFinder sign firmly down until screws are seated into the narrow portion of the keyhole slot.
14. Tighten the screws only until the AddressFinder sign is snug to the wall.
15. From inside, gently pull straw and any excess low-voltage wire through the wall.
16. Remove and discard the straw.
17. 18v Plug-in adapter with screw terminals: connect 1 of the low-voltage wires with fork to a screw terminal on the 18v adapter. Then connect the second wire fork to the other screw terminal on the 18v adapter.

18. Cut the low-voltage wire to desired length and strip off plastic insulation covering, allowing sufficient copper wire to be exposed (about 1/2" or 13mm).
19. Using the wire nuts, connect 1 of the low-voltage wires from the AddressFinder sign to 1 of the wires from the extra length of low-voltage wire provided. Then connect the second wire from the AddressFinder sign to the other wire from the extra length of low-voltage wire.
DO NOT CONNECT all wires together as this will damage the Plug-in Adapter.
20. Secure wire along the wall (**DO NOT use steel staples to fasten wire to wall or ceiling**) and bring to the closet electrical outlet.
WARNING: DO NOT use steel staples to fasten wire to wall or ceiling, as this will damage the Plug-in Adapter.
21. Plug the Plug-in Adapter into the electrical outlet.
WARNING: Please ensure the AddressFinder sign is installed prior applying power.
22. At this point, the AddressFinder sign is now functional.

Troubleshooting

- | | |
|---|---|
| <ol style="list-style-type: none"> 1a) Does the AddressFinder sign flicker? 1b) Does the AddressFinder sign go off when dark? <ul style="list-style-type: none"> • Remove any other light sources nearby • Is the electrical outlet controlled by a light switch | <ol style="list-style-type: none"> 2) Does the sign stay on all the time? <ul style="list-style-type: none"> • remove any obstructions from the photo sensor |
|---|---|

For all other questions or for Customer Assistance, please call during the hours of 9:00am to 5:00pm EST (Eastern Standard Time) Local: 905 – 265 – 8586 or email us at sales@ledlitesolutionsinc.com

WARRANTY / GUARANTEES	RETURNS POLICY
<p>All of our AddressFinder products come with a 1-year warranty against manufacturing defects. We also warranty the LED's themselves for a period of 3-years. Should your product fail within the 1-year period then we may replace, repair or exchange at our discretions, in accordance with our Returns Policy. The warranty does not cover weathering or surface scratches as this is considered normal wear. The warranty also does not cover any product that has been altered or damaged due to: normal wear; abuse; improper maintenance; improper use; disassembly of parts and/or attempted repair; modification or alteration by anyone.</p> <p>We carefully select products of the highest quality so problems are rare. Also every product is checked and tested before it is shipped so this process virtually eliminated those annoying "dead-on-arrival" situations.</p> <p>LED Lite Solutions Inc will not be responsible for any misuse, neglect or failure to install or use a product in such a way that it is not recommended or differs from the manufacturers instructions.</p>	<p>All our products carry a 1-year warranty from date of purchase. This warranty is for coverage against manufacturing defects or malfunctions. A product may be returned due to failure provided it is complete with all parts, instructions and undamaged packaging – basically send it back the same way it was received. If not, we are unable to accept the return.</p> <p>LED Lite Solutions Inc will not pay for the transportation costs for returning the defective product. The defective product must be shipped, freight prepaid; to LED Lite Solutions Inc. The repaired or its replacement will be returned to the customer provided the customer prepays the freight charges. LED Lite Solutions Inc shall have not liability whatsoever for products lost or damaged in transport.</p> <p>We recommend that you carefully read and understand the product descriptions and technical specifications prior to purchase. Please take great care when you have any doubts as to the product not meeting your requirements you should not proceed with using it or installing it. Keep all parts and packaging (undamaged) to assist with a return authorization.</p>